



Trucks Filters (Hino - Isuzu - Fuso) Genuine & Others

Hino Filters (up to 1997)

Model	Year	Oil Filter	Fuel Filter/Fuel Tank	Fuel Filter/Engine	Air Filters
FA/FB	1987-91	156071750A	235011010A	234011411A	out 178012620A in 178012610A
FA/FB	1992-07	156071750A	235011010A	234011411A	178012800A
16 Series	1986 - 87	156071740A	235011010A	234011411A	out 178012480A in 178012460A
17 Series	1984 - 91	156071740A	235011010A	234011402A	out 178012480A in 178012460A
19 Series	1984 - 91	(1) 156071740A (1) 156071860A	235011010A	234011402A	out 178012480A in 178012460A
20 Series	1992	(1) 156071740A (1) 156071860A	235011010A	234011402A	178012810A
FD2218	1993 - 97	(1) 156071740A (1) 156071860A	235011010A	234011402A	178012810A
FD2218LP	1993 - 97	(1) 156071740A (1) 156071860A	235011010A	234011402A	178012810A
FF3020	1993 - 97	(1) 156071740A (1) 156071860A	235011010A	234011402A	178012810A
SG3320	1993 - 97	(1) 156071740A (1) 156071860A	235011010A	234011402A	178012810A
FG22	1984- 86	(1) 156071740A (1) 156071860A	235011010A	234011402A	out 178012480A in 178012460A
SG22	1984- 86	(1) 156071740A (1) 156071860A	235011010A	234011402A	out 178012480A in 178012460A
SG23	1987 - 91	(1) 156071740A (1) 156071860A	235011010A	234011402A	out 178012480A in 178012460A
FF23	1992	(1) 156071740A (1) 156071860A	235011010A	234011402A	178012810A
SG23	1992	(1) 156071740A (1) 156071860A	235011010A	234011402A	178012810A
SG3323	1993 - 97	(1) 156071740A (1) 156071860A	235011010A	234011402A	178012810A
SG5523	1993 - 97	(1) 156071740A (1) 156071860A	235011010A	234011402A	178012810A
FFC1	1986 - 88	Cummins # 3908615A	N/A	Cummins # 3903202	out 178012480A in 178012460A

Hino Filters (1998 - up)

Model	Year	Oil Filter	Fuel Filter/Fuel Tank	Fuel Filter/Engine	Air Filters
All Models	1998 - 03	156072170A	234011440A		
FA/FB	1998 - 02			23411510A	178013000A
FD/FE/FF/SG	1998 - 02			234011402A	178012810A
All Models	2003			234011510A	

Hino Power Steering & A/T Filters

Model	Year	Reserv. Strainer	Reserv. Filter	Auto Transmission
All models	1998 - 03	472281050A		
FD/FE/FF/SG	1998 - 03		4436110670A	
All Models	1998 - 01			349261041A

Fuso Filters

Model	Year	Oil Filter	Fuel Filter	Air Filters	A/T Filter
FE-434-444	1987 - 91	ME014833 PRI	ME016872	MB12098 (NIC)	KT223004(JATCO)
		ME014838 BYP		ME033717 (IC)	MJK22775 (A727)
FE-439-449	1992 - 95	ME215002	ME015254	ME033717	KT223004(JATCO)
FE-639-649	1996 - 04	ME215002	ME015524	ME017246	KT223004(JATCO)
FE-640	2001 - 04	ME088532	ME132525	ME017246	ME609885+FP100056
FE 434	1990 - 91	ME014833 PRI	ME016872	ME033717	N/A
		ME014838 BYP			
FG 345	1992 - 94	ME215002	ME015254	ME033717	N/A
FG 639	1998 - 04	ME215002	ME015254	ME017246	ME609885+FP100056
FG 649	2002 - 04	ME215002	ME015254	ME017246	N/A
FH100	1988 - 91	ME014833 PRI	ME01524	ME033717	KT423001
		ME014838 BYP			
FH100	1992 - 95	ME215002	ME056670	ME033717	KT423001
FH211	1996 - 02	ME215002	ME056670	ME033603	KT423001
FH211	2003 - 04	ME215002	ME056670	ME073160	KT423001
FH210	2003 - 04	ME088532	ME132525	ME073160	ME609885+FP100056
FK415-455	1986 - 87	ME034878 PRI	ME035394	ME033717	KT423001
		ME034879 BYP			
FK415-455	1988 - 91	ME130968	ME015254	ME033603	KT423001
FK417-457	1992 - 95	ME130968	ME056670	ME073252	KT423001
FK617	1996 - 04	ME130968	ME056670	ME073821	KT423001
FM555	1986 - 87	ME034878 PRI	ME035394	ME033603	N/A
		ME034879 BYP			
FM555	1988 - 91	ME130968	ME015254	ME033603	N/A
FM557	1990 - 91	ME130968	ME015254	ME073252	N/A
FM557	1992 - 95	ME130968	ME056670	ME073252	N/A
FM617-657	1996 - 04	ME130968	ME056670	ME073821	KT423001

Isuzu Filters

KS 22

	<u>Model</u>	<u>Year</u>	<u>Oil Filter</u>	<u>Fuel Filter</u>	<u>Air Filters</u>
	ALL	1985	5-87810-293-0	8-94408-078-0	5-14215-030-0
			940056601	5-87810-050-0	

NPR / W4 / W3500 / W4500 / W5500 (DIESEL)

	PARTIAL	1986 - 91	2-90654-930-0		
			94360419		
	MAIN	1986 - 91	2-90654-950-0		
			97728672		
	ALL	1992 - 98	2-90654-600-0		
			97719921		
	4HE1	99 - UP	2-90654-800-0		
			97148270		
FEED PUMP	ALL	1986 - 98		8-94408-078-0	
				94408078	
	ALL	1999 - UP		2-90654-640-0	
				94392474	
	ALL	1986 -3/86			8-94156-052-0
	Cab Chassis	4/86 - 95			8-94430-250-0
	Str Chassis	4/86 - 95			8-94156-052-0
	Ryder	5/95 - 98			8-97021-607-0

NPR / W4 / W3500 / W4500 (GAS)

	ALL	1993 - 95	8-06438-384-0		
	5.7L V8	96 -02	8-25160-561-0		
	6.0L V8	2003 - UP	8-25010-633-0		
	ALL	93 - 02		8-25055-052-0	
	ALL	93 - 9/95			8-06484-235-0
	ALL	1996 - UP			8-94430-250-0

NRR / W5

	PARTIAL	1988 - 1994	2-90654-820-0		
			94054123		
	MAIN	1988 - 1994	1-13200-487-2		
			94037791		
FEED PUMP	ALL	1988 - 91		8-94408-078-0	
	ALL	1988 - 94		8-94392-474-0	
	OUTER	1988 - 94			1-14215-172-0
					94058234
	INNER	1988 - 94			1-14215-111-0
					94037809

FRR / W5 / WT5500

	MAIN	1995 - UP	1-13200-487-2		
			94037791		
	PARTIAL		2-90654-820-0		
			94054123		
	ALL	1995 - UP		8-94393-474-0	
WATER SEP	ALL	2000 - UP		1-13240-194-0	
	ALL	1995 - 99			1-14215-181-0
					94058235
	OUTER	2000 - UP			1-14215-181-0

				94058235
	INNER	2000 - UP		1-14215-151-0
				94048864

FSR / W6 / T60 / T6000

ELEMENT	PARTIAL	1987 - 7/87	1-87810-334-0	
			94038680	
	MAIN	1987 - 02	1-13200-487-2	
			94037791	
SPIN ON	PARTIAL	8/87 - 96	2-90654-820-0	
			94054123	
FEED PUMP	ALL	1987 - 1991		8-94408-078-0
	ALL	1987 - 4/98		8-94392-474-0
WATER SEP	ALL	1997 - 02		8-15618-921-0
	ALL	5/98 - 2002		8-94392-474-0
	ALL	1987 - 94		1-14215-172-0
				94058234
	INNER	1987 - 10/88		1-14215-111-0
				94037809
	ALL	1995 - 96		1-14215-181-0
				94058235
	6HE1	1997 98		8-12386-667-0
	SECONDARY	1998 - 02		8-12474-421-0
	PRIMARY	1998 - 02		8-12471-801-0

FTR / W7M / T70 / T7000

	MAIN	1984 - UP	1-13200-487-2	
			94037791	
ELEMENT	PARTIAL	1984 - 7/87	1-87810-334-0	
			94038680	
SPIN ON	PARTIAL	8/87 - 96	2-90654-820-0	
			94054123	
	ALL	1984 - 4/98		8-94392-474-0
FEED PUMP	ALL	1987 - 91		8-94408-078-0
WATER SEP	ALL	1997 - 02		8-15618-921-0
	ALL	5/98 - UP		8-94392-474-0
	INNER	1984 - 88		1-14215-111-0
				94037809
	OUTER	1984 - 94		1-14215-172-0
				94058234
	ALL	1995 96		1-14215-181-0
				94058235
	6HE1	1997 98		8-12386-667-0
6HK1	PRIMARY	1998 - UP		8-12471-801-0
6HK1	SECONDARY	1998 - 02		8-12474-421-0

FVR / W7H / T70 / T7000

	MAIN	1986 - UP	1-13200-487-2		
			94037791		
6SA1-T	PARTIAL	1986 - 1991	1-13240-163-2		
			97714534		
6BG1-T/6HE1-T	PARTIAL	1990 - 96	2-90654-820-0		
			94054123		
	ALL	1986 - 4/98		8-94392-474-0	
FEED PUMP	ALL	1988 - 90		8-94408-078-0	
WATER SEP	ALL	1997 - 02		8-15618-921-0	
	ALL	5/98 - UP		8-94392-474-0	
	INNER	1986 - 10/88			1-14215-125-0
					94048864
	OUTER	1986 - 10/88			1-14215-152-0
					94048865
	6BG1-T	1990 - 94			1-14215-172-0
					94058234
	6HE1-T	1995 - 96			1-14215-181-0
					94058235
	6HE1	1997- 98			8-12386-667-0
	PRIMARY	1998 - UP			8-12471-801-0
	SECONDARY	1998 - 02			8-12474-421-0
	OUTER	11/88 - 5/89			1-14215-181-0
					94058235

EVR / W7T

6SA1-T	PARTIAL	1987 - 91	1-13240-163-2		
			97714534		
	MAIN	1987 - 92	1-13200-487-2		
			94037791		
6BG1-T	PARTIAL	1990 - 92	2-90654-820-0		
			94054123		
	ALL	1987 - 92		8-94392-474-0	
FEED PUMP	ALL	1988 - 90		8-94408-078-0	
	OUTER	1987 - 10/88			1-14215-152-0
					94048865
	INNER	1987 - 10/88			1-14215-125-0
					94048864
	6SA1-T	1990 - 91			1-14215-181-0
					94058235
	6BG1-T	1992			1-14215-172-0
					94058234
	OUTER	11/88 - 5/89			1-14215-181-0
					94058235

FXR / T8000

	6HK1	2004 - UP	1-13200-487-2		
			94037791		
	ALL	2004 - UP		8-94392-474-0	
	6HK1	2004 - UP			8-12471-801-0